

Addendum manual PC4 for firmware version 02.00

Controller mode

Hold down both shift keys for about 2 seconds to send a snapshot of all pots. A flashing red light indicates successful sending.

System mode

Start and leave system mode by pressing both shift keys at the same time shortly. Active system mode is indicated by the yellow sys-LED.