

Addendum manual UC44 for firmware version 02.01

Controller mode

- Fader mute function by holding down the red shift key and move any fader
- Faderpos-indication by holding down the red shift key and move any fader:
green LEDs show the sync of faderposition and feedback data
- Snapshot function by green key 16 while holding down red shift key:
send values of all faders (current positions)

Edit mode

- new encoder scale 'on' to show only two states
value greater than 0 = On
value equal 0 = Off
- new fader/encoder type 'note' to send note commands:
move fader to upper half = note on
move fader to lower half = note off
turn encoder clockwise = note on
turn encoder anti-clockwise = note off