Traktor Pro setup 'faderfox FX3 V01.tsi'

Dry / Wet

FX Select (advanced)

FX parameter 1
or
FX1 amount

FX1 Select (chained)

FX parameter 2
or
FX2 amount

FX2 Select (chained)

FX parameter 3
or
FX3 amount

FX3 Select (chained)

Switch on/off FX (advanced)

Assign deck A to the FX-slot

Select preset 1 for selected slot
press again to toggle
advanced/chained mode
(indicated by green led 1,
blinks during chained mode)

FX reset (advanced)
or
FX1 on/off (chained)

Assign deck B to the FX-slot

Select preset 2 for selected slot
press again to toggle
advanced/chained mode
(indicated by green led 2,
blinks during chained mode)

FX button 1 (advanced)
or
FX2 on/off (chained)

Assign deck C to the FX-slot

Select preset 3 for selected slot
press again to toggle
advanced/chained mode
(indicated by green led 3,
blinks during chained mode)

FX button 2 (advanced)
or
FX3 on/off (chained)

Assign deck D to the FX-slot

Select preset 4 for selected slot
press again to toggle
advanced/chained mode
(indicated by green led 4,
blinks during chained mode)

Hold preset button to
select presets by the green buttons
and select FX types by the pots
(FX types will be stored in device
by releasing preset button)

Effect settings snapshot



Browse thru track list
Push to reset effect LFO

Browse thru tree
Push to expand/collapse tree

Sys led
lit = system mode is active
blinks = controller isn't recognized

(Press both load A & B buttons
to get traktors monitor state)

Load selected track into deck

Play / pause

(Press both Load C & D buttons
and hold for about 1 second
to enter/leave system mode)

! Hold shift button for 2nd functions written on yellow (light gray) background